

PLEASE READ THESE INSTRUCTIONS CAREFULLY BEFORE INSTALLATION  
PLEASE RETAIN INSTRUCTIONS FOR FUTURE REFERENCE



# Cryos

## Installation Instructions




### IMPORTANT PLEASE READ BEFORE INSTALLATION

- Before commencing installation ensure the electricity is switched off at the mains.
- Installation should be carried out in accordance with the latest edition of the I.E.E. Wiring regulations (BS7671) taking into account the latest building regulations.
- Installation should be carried out by a qualified electrician.
- Ensure all electrical connections are tight with no loose strands, including factory made connections.

### WARNINGS


- Use only with the driver supplied
- This luminaire is for indoor use only
- **IMPORTANT** The driver must not be covered by ceiling insulation material; this will reduce the units operational lifetime, invalidate the guarantee and may cause a risk of fire. The driver can be installed up to 20m from the fitting. Free airspace diagram to be observed

This install manual covers the following products:




CY-AD-MW/xxx-xxx-xx-xx/xx

1.




Ø85mm ceiling cut out

2.



220-240V

3.



4.





Diagram showing required airspace  
(fixing mechanism in diagram differs from actual)

Photonstar LED Group plc  
Unit 8, Westlink,  
Belbins Business Park  
Romsey  
Hampshire  
SO51 7JF

Tel: +44(0) 2381 230 381  
Email: sales@photonstarled.com  
Web: www.photonstarlighting.co.uk